« Quick Start Guide »

BlueSonic
Bluetooth Portable Speakers

Quick Start Guide

« Inside the box »

- One set of BlueSonic Wireless Speakers
  - USB Bluetooth Dongle v2 + EDR
  - One Audio lead with 3.5mm plugs
  - One BlueSonic User Guide
  - One AC wall charger
  - One Quick Start Guide.

« Optional Extras »

- A2DP Audio Streamer with 3.5mm Jack
- External Microphone

« Pairing BlueSonic to a Mobile Phone »

1. Charge the BlueSonic for at least 3 hours before use. Reboot the mobile phone.
2. On the rear of the BlueSonic turn the power switch to ON.
3. Press and Hold the Play/Pause button until you hear a melody (6 seconds).
4. Turn Bluetooth ON in your phone.
5. Perform a device discovery to search for the BlueSonic. (Some devices require you to pair once for High Quality Audio and again for Handsfree, E.G HP 6515. Other phones require pairing only once but will enable both services E.G Samsung D600)
6. When devices are displayed, select the BlueSonic. Enter Passkey "1234".
7. Set the BlueSonic as a trusted/authorised device, if optional in your phone.
8. Finish and exit.
9. If required, select the BlueSonic in the Bluetooth devices list and hit Connect.
10. Refer to your phones User Manual for any additional steps

To pair up to 7 more devices; phones, pda's, computers or A2DP streamers –

1. Turn the device on.
2. Repeat steps 3 – 8 for each device you want to pair.

« Function / Button matrix »

Feature		►II	I◄◄	►►I			Conditions
Pairing		Press/Hold					Standby
Cancel Pairing		Press/Hold					During Pairing
Pick Up	Short						To Telephone
Hang Up	Short						During Communication
Voice Dialing	Short						Standby
Reject a Call	Long						Receive Calling
Last Call Redial	Double						Standby
Switch to Handset	Long						During Communication
Cancel Voice Dialing	Short						During Voice Dialing
Volume Up						Short	During Communication
Volume Down					Short		During Communication
Connect To Voice	Short						Disconnected
Connect To Stereo		Short					Disconnected
Play		Short					Stop or Pause
Pause		Short					Playing
Stop		Long					Playing
Forward				Short			Playing
Backward			Short				Playing



Operation Buttons and Symbol Definition

- **Short Press** = Press and release less than 1 second
- **Long Press** = Press and release for 2 seconds
- **Double Click** = Click twice within 0.5 second
- **Press/Hold** = Press and hold the key for more than 6 seconds

Blue ant wireless®

《 Quick Start Guide 》

BlueSonic
Bluetooth Portable Speakers

《 BlueSonic Overview 》



《 Reconnecting the BlueSonic 》

When the BlueSonic has been disconnected (by switching off or going out of range) you will need to reconnect by:

1. Short Press the Phone Button or the Play/Pause Button on the front panel. For voice or music respectively.
2. Or select the BlueSonic in the Phones Bluetooth Menu or in Bluesoleil on the PC and select Connect

《 Pairing BlueSonic to your Windows PC/Laptop 》

1. Run the Bluesoleil Setup.exe file on the included Driver CD, follow the prompts and reboot your PC
2. Insert the USB Bluetooth Dongle, name your computer and select the type of PC you're using.
3. Turn the Power switch to ON at the rear of the BlueSonic.
4. Press and Hold the 「 ▶II 」 button for about 6 seconds and you hear a distinct melody
5. Click on the Orange Sun to activate a 'Search for devices'
6. Right click on the BlueSonic icon and select Pair. Enter Passkey "1234".
7. Right click on the BlueSonic icon and select Refresh Services.
8. Again right click on the BlueSonic icon and select Default Audio Device so it is ticked.
9. Short Press the 📞 button on the BlueSonic to Connect a Voice Connection or
10. Short Press the 「 ▶II 」 Play/Pause button on the BlueSonic to Connect a Stereo Connection (Both connections cannot be made at once)

《 LED indicator chart 》

Pairing	Blue rapid blink
During Communication	Blue rapid blink 3 times per second
Playing Music	Blue rapid blink 2 times per second
Connected and Standby	Blue Blink once per second
Standby without Connected	Blue Blink rapid once every 2 seconds
Low Battery	Amber continuing blinking, the lower the faster
Charging	Amber light on
Charging complete	Green light on

Blue ant wireless®